



WILAPLAT Pen Plating Baths

Rhodinette Silver Bath

Article No. 3010300102

Description

The Silver Bath formulated for the Rhodinette Pen Plating System forms an extremely bright, durable deposit for decorative applications. In addition to multicolouring processes on jewellery pieces, they are also ideally suited for repair or restoration work.

Application

WILAPLAT Pen Plating Baths are used in pen plating units such as the Rhodinette II. The coating requires a perfect cleaning and degreasing of the work pieces. Electrical current must flow between the work piece and the contact clip or plate. Upon completion of the coating process the electrolyte is rinsed off.

It is absolutely essential to avoid drag out of the electrolyte solution and a separate plating pen must be used for every Rhodinette colouring bath.

Operating Data

Silver Content	3.0 g / 100 ml
Temperature	20-30 °C
Setting Rhodinette II	1 - 3

Supply Form

Ready for use

Regeneration

Not necessary, as metal is completely depleted

Warning

Chemicals and materials used in electro-plating techniques can be corrosive or poisonous. During use, storage, transportation and disposal, the relevant guidelines must be observed.

For further information see The EEC Safety Data Sheets