



HI-TECH EQUIPMENT FOR PRECIOUS MATERIALS

Engelse Wandeling 5 B-8500 Kortrijk
Tel . ..32.56.22.05.49 Fax . ..32.56.22.90.21
www.buko.be– info@buko.be

MAGNETIC TUMBLER MINI



1



2

Instructions for Use

- **Maximum total weight of pins and workpieces: 100 g.**
- Place the pins (1) in the plastic bowl with fresh water. (level about 1 cm above the pins) and add a teaspoon of polishing soap FC625 (2).
Caution: If the bowl is too full, water may overflow.
- Place the workpieces in the plastic bowl. Ensure that all workpieces are fully submerged and not stacked on top of each other. If necessary, reduce the number of workpieces.
- Replace the liquid as often as needed for optimal results.
- Start the machine and set the timer. General guidelines:
 - Silver and gold:** 20-30 minutes
 - Yellow gold:** 30-40 minutes
- **Always** keep the lid on the bowl while the machine is running.
- At the end of the set time, the machine automatically switches to standby mode.
- The machine rotates in both directions (left and right)

Note

It is normal for the machine to become slightly warm during operation.
To extend the life of the machine, always remove the lid after use to allow it to cool properly.

Wij wish you success with using your magnetic polishing machine.



CONTROL PANEL

1. Timer
2. Direction – choose between single direction of alternating