



HI-TECH EQUIPMENT FOR PRECIOUS MATERIALS

Buko nv - Engelse Wandeling 5 – 8500 Kortrijk

www.buko.be - info@buko.be

PRODUCT: ANTIOXIDANT (V7)

The V7/R11 product is used to clean stainless steel balls/needles when they are dirty, or to protect the balls/needles from oxidation if they are not being used for a while.

Cleaning instructions :

Add a theaspoon of antioxidant powder to water and top up with water until the balls/needles are completely submerged. Leave to run for 15 minutes. Then rinse thoroughly and, if necessary, repeat the process until the balls/needles are clean and shiny again.

Rinse thoroughly several times and add the FC 625 compound tot he water.

Use of oxidation protection :

Add a theaspoon of antioxidant powder to water and top up with water until the balls/needles are completely submerged. Run for 15 minutes. You can then store the balls/needles for a longer peroid. The balls/needles can be left to dry in the water with the V7 without any problem.

