



## WILAPLAT Pen Plating Baths

### Rhodinette Gold Baths

Article No. 3010100102 Fine Gold

Article No. 3010100202 Yellow Gold

Article No. 3010100302 Pale Gold

Article No. 3010100402 Red Gold

#### Description

The gold baths formulated for the Rhodinette Pen Plating System produce an extremely bright, durable deposit for decorative applications. In addition to multi colour processes on jewellery pieces, they are also ideally suited for repair or restoration work.

#### Application

WILAPLAT pen plating baths are for use in pen plating units such as the Rhodinette II. The coating requires a perfect cleaning and degreasing of the work pieces. Active electrical contact must be established between the work piece and the contact clip or plate. Upon completion of the coating process the electrolyte is rinsed off.

As it is absolutely essential to avoid drag out of the electrolytes, a separate plating pen must be used for every gold colouring solution.

#### Operating Data

**Gold Content**

2.0 g/100 ml

**Temperature**

20-30°C

**Rhodinette II Setting**

4-10 (for fine, pale and yellow gold)

2-8 (for red gold)

#### Supply Form

Ready for use

#### Regeneration

Not necessary, as metal content is completely depleted

#### Warning

Chemicals and materials used in electro-plating techniques can be corrosive or poisonous. During use, storage, transportation and disposal the relevant guidelines must be observed.

For further information see the ECC Safety Data Sheets