



HI-TECH EQUIPMENT FOR PRECIOUS MATERIALS

Engelse Wandeling 5 B-8500 Kortrijk  
Tel . ..32.56.22.05.49 Fax . ..32.56.22.90.21  
[www.buko.be](http://www.buko.be)– [info@buko.be](mailto:info@buko.be)

## PROFESSIONAL MAGNETIC POLISHING TUMBLER



### **1. Technical specifications**

Power supply : 220V 50/60Hz (110V on request)  
Power : 360 Watt  
Dimensions : 400 x 300 x 250 mm  
Weight : 18 kg

### **2. Placement**

Place the machine in a well-ventilated room on a sturdy stable surface. Leave approximately 50 cm of space around the machine to allow proper cooling and a safe working environment.

Check that the voltage indicated on the machine matches the electric supply. The machine is supplied with a power cable of approximately 1,5 m in length.

For user safety, we recommend installing a 6 Amp fuse between the machine and the electrical network. The machine must be connected in accordance with current safety standards. A properly functioning grounding is absolutely necessary. Ensure the machine is switched off before connecting it.

### **3. Instructions for use**

Before using a new machine, it is essential to read the manual. Any damage or malfunction caused by failure to follow the instructions cannot be attributed to the manufacturer.

- Place the pins in the plastic bowl with fresh water (level about 1 cm above the bottom) and add 10 ml of polishing soap FC625.

- Place the workpieces in the plastic bowl (capacity: approx. 200–300 g). Ensure that all workpieces are fully submerged and not stacked. If necessary, reduce the number of workpieces.
- Start the machine and program the required polishing time. Guidelines:
  - Silver and white gold: 20–30 minutes
  - Yellow gold: approx. 30–40 minutes
- Always keep the lid on the plastic bowl during operation.
- At the end of the set time, the machine automatically switches to standby mode.
- Add or remove workpieces only when the container has first been removed from the machine.

**Note :**

It is normal for the machine to become slightly warm during operation. Machines of the type MP/E and MP/I comply with current safety standards according to CE legislation. In case of emergency, press the red emergency stop button. This will automatically lock the machine. To restart the machine, the emergency stop button must be released.

We wish you great success with using our magnetic polishing machines.